



Navigating to a Destination



To navigate to a point using **Where To?**:

1. On the Main Menu, touch **Where To?**.
2. Touch a category.
3. Touch the item to which you want to navigate.
4. Touch **Go**. A colored line indicates your course.
5. Touch  > **Compass**.
6. Use the compass to navigate to your destination.

To navigate to a point on the map:

1. On the Main Menu, touch **Map**.
2. Touch the point on the map.
3. Touch the information button at the top of the screen.
4. Touch **Go** >  > **Compass**.
5. Use the compass to navigate to your destination.

Information button



To stop navigating, touch **Where To?** > **Stop Navigation**.

Using the Compass

To open the Compass page:

On the Main Menu, touch **Compass**.

Hold the compass level when navigating.

The bearing pointer points to your destination, regardless of the direction you are moving.

If the bearing pointer points toward the top of the compass, you are traveling directly toward your destination. If it points any other direction, turn toward that direction until the arrow is pointing toward the top of the compass.

Calibrate the compass after moving large distances, experiencing temperature changes, or changing the batteries.



To calibrate the electronic compass (Oregon 300, 400t, 400c, and 400i):

1. While outdoors, hold the Oregon level and do not stand near objects that influence magnetic fields, such as cars, buildings, or overhead power lines.
2. On the Main Menu, touch **Setup** > **Heading** > **Press To Begin Compass Calibration**.
3. Touch **Start** and follow the on-screen directions.



Creating Routes and Using Tracks

To create and navigate a new route:

1. On the Main Menu, touch **Route Planner** > **<Create Route>** > **<Select First Point>** to select a starting point.
2. Touch a category.
3. Touch the first item on the route.
4. Touch **Use** > **<Select Next Point>**.
5. Repeat until the route is complete.
6. Touch  to save the route.
7. Touch  > **Where To?** > **Routes** to navigate the route.

To record your tracks:

1. On the Main Menu, touch **Setup** > **Tracks** > **Track Log**.
2. Touch **Record, Do Not Show** or **Record, Show On Map**.

If you select **Record, Show On Map**, a dashed line on the Map page indicates your track.

To clear your current track:

On the Main Menu, touch **Setup** > **Reset** > **Clear Current Track** > **Yes**.

Please visit www.garmin.com for additional documentation and information.

GARMIN

Oregon™ series
quick reference guide



Installing the Batteries

See the *Important Safety and Product Information* guide in the product box for product warnings and other important information.

The Oregon operates on two AA batteries (not included). Use alkaline, NiMH, or lithium batteries.

Use premium batteries for optimal performance and maximum battery life. The best performance is provided by lithium batteries and NiMH rechargeable batteries less than one year old with a capacity greater than 2500 mAh.

To install the batteries:

1. Lift the latch and remove the battery cover.
2. Insert the batteries, observing polarity.
3. Replace the battery cover and push the latch down.



NOTE: Remove the batteries when you do not plan to use the Oregon for several months. Stored data is not lost when batteries are removed.

To select the battery type:

1. On the Main Menu, touch **Setup > System > Battery Type**.
2. Select **Alkaline**, **Lithium**, or **NiMH**.

Getting Started

To turn the Oregon on:

Press the **Power** key.

To turn the Oregon off, press and hold the **Power** key.

To adjust the backlight level:

1. While the Oregon is on, press and quickly release the **Power** key.
2. Touch or to adjust the brightness levels.

To lock or unlock the screen:

1. Press and quickly release the **Power** key.
2. Touch **Lock Screen** (or **Unlock Screen**).

To acquire GPS satellite signals:

1. Go outdoors to an open area, away from tall buildings and trees.
2. Turn the Oregon on. Acquiring satellite signals can take a few minutes.

The bars on the Main Menu indicate satellite strength. When the bars are green, the Oregon has acquired satellite signals.



Main Menu

Using the Map Page

To access the Map page, touch **Map**. Your current location is indicated by a location marker .

To zoom in or out:

Touch or .

To pan across the map:

On the Map page, touch and drag the screen.

To review detailed information about a point on the map:



1. Pan to the location you want to review, if necessary, and then touch it.
2. Touch the information button at the top of the screen for additional information.

To show or hide data fields:

1. On the Main Menu, touch **Setup > Map > Data Fields > Show Data Fields**.
2. Touch **Never**, **When Navigating**, or **Always**.

To change the Map page data fields

1. On the Map page, touch one of the data fields.
2. Touch a data type.



Creating and Editing Waypoints

To mark your current location as a waypoint and edit the waypoint:

1. On the Main Menu, touch **Mark Waypoint**.
2. Touch **Save and Edit**.
 - Touch the attribute you want to change.
 - Touch letters, numbers, or symbols to make the changes.
 - Touch (except when changing a symbol). Change other attributes, if necessary.
 - Touch .

To edit a waypoint:

1. On the Main Menu, touch **Waypoint Manager**.
2. Touch the waypoint you want to edit.

To delete a waypoint:

1. On the Main Menu, touch **Waypoint Manager**.
2. Touch the waypoint you want to delete.
3. Touch **Delete Waypoint**.

To reposition a waypoint to your current location:

1. On the Main Menu, touch **Waypoint Manager**.
2. Touch the waypoint you want to reposition.
3. Touch **Reposition Here**.

